

Cardia Biohybrid™ H-M01

Rigid Moulding Resin

High Renewable Resource Content

Description

Cardia Biohybrid™ H-M01 is based on a blend of thermoplastic starch (TPS) and polyolefin's. This grade of resin is compatibilised to offer a high level of mechanical strength, good impact resistance and toughness. The resin is based on corn starch which is a renewable material.

- A biohybrid resin offering a significant reduction in carbon footprint (compared to polyolefins PE/PP)
- An effective contribution to sustainability where biodegradability/compostability is not required
- Designed for thin and thick gauge rigid moulding and extrusion applications.

Specifications and Compliances

Cardia Biohybrid™ H-M01 is formulated with 50% of renewable thermoplastic starch polymer. This resin is suitable for a wide range of products manufactured by injection moulding or extrusion processes. Due to its content of polypropylene the material is not a fully biodegradable polymer and it is not intended for ultimate disposal in commercial composting facilities. If biodegradability or compostability is required, use of Cardia Compostable B-M or TBM resin is recommended.

Application Examples

- Injection moulded products such as cutlery, toothbrushes, combs, shavers, golf-tees, etc.
- Stakes and pegs
- Horticultural products such as flower pots and stakes
- Injection moulded containers, caps and closures
- Disposable plates and produce trays

Physical Properties of Cardia Biohybrid™ H-M Resin

Properties	Test Method	Value	Unit
Melt flow index	ASTM D1238	3.1- 4.7 g/10 min	(2.16 kg/ 190°C)
Density	ASTM D4883	1.07	g/cm3
Melting Temperature	ASTM D3418	150-165	°C
Tensile strength at break	ASTM D638	> 15	MPa
% Elongation at break	ASTM D638	> 16	%
Izod Impact-Notched	ASTM D256	9.7	kJ/m2 or J/m
Mold Shrinkage		1	%

Transport, Storage and Handling

Cardia Bioplastics™ Materials should be transported, stored and handled in cool and dry environments without exposure to direct sunlight. More information can be retrieved from the Processing Guidelines available through your Cardia Bioplastics sales representative.

Safety

Material Safety Data Sheets (MSDS) are available. Please contact your Cardia Bioplastics sales representative.

Processing Conditions

Cardia Biohybrid™ H-M01 materials can be easily processed on standard plastic process equipment. Processing guidelines are unique to this material and are available on request from the Cardia Bioplastics sales representative.

Food Contact

In certain applications Cardia Biohybrid™ H-M01 can be suitable for direct contact with foodstuffs as per Directive 2002/72/EC (previously 90/128/EEG and amendments). More information can be found in the Info “FOOD CONTACT Compliance of Cardia Biohybrid Resins” available on our Website. In order to discuss a specific food contact application please contact Cardia Bioplastics’ Technical Service.

Disclaimer

This information is offered solely for your consideration and verification and should not be construed as a warranty of representation for which Cardia Bioplastics assumes legal liability, except to the extent that such liability is imposed by legislation and cannot be excluded. Values quoted are the results of tests on representative samples and the product supplied may not conform in all respects. Cardia Bioplastics reserves the right to make any improvements or amendments to the composition or any grade or product without alteration to the product code. In using Cardia Bioplastics products you must establish for yourself the most suitable formulation, production method and control tests to ensure the uniformity and quality of your product is in compliance with all laws.